



HOW TO ORDER

BODY/BASE OPTIONS



PILOT VALVE OPTIONS



NOTE: 1. The valve less base is always the same for internal or external pilot. These options are effected in the base or manifold.

- 2. Bottom ports: Refer to modification table below.
- 3. When ordering an external pilot connection for manifold bases, a common external pilot port is standard. One connection only is required for all the valves in the manifold whether single or double solenoid.
- 4. Manifold Accessories: Inlet & Exhaust Isolator #28367.

MODIFICATIONS

MODIFICATIONS			
	MOD. NO.	DESCRIPTION	MODEL AVAILABILITY
	0002 0004	Bottom inlet, exhaust, & cylinder ports (no side ports) Full side porting and additional bottom inlet, exhausts, and cylinder ports	Available on individual base 3/4" only Available on individual base 3/4" only
	0112	Side inlet & exhaust with bottom cylinder ports (no end cylinder ports)	3/4" individual base & 3/4" & 1" manifold base
	0210	1-1/4" bottom inlet	Manifold base
	0364	1-1/4" bottom inlet & 3/4" or 1" bottom cyl.	Manifold base

TO ORDER Add the appropriate modification number after the valve number, EXAMPLE: 6611A-211-FM451DA MOD 0002.